


# GENUINE PARTS FILTER KITS



# **BOBCAT GENUINE FILTERS AGAINST LOCAL SOURCE FILTERS**

# **ENGINE OIL FILTER**

# HYDRAULIC OIL FILTER

# **BOBCAT FILTER**



Cellulose media 10 micron © > 2 Media area: 0.2046 m²

Greater media surface with 3 times greater filtration performance!

# **COMPETITIVE FILTERS\***



Cellulose media 30 micron © > 2 Media area: 0.183 m<sup>2</sup>



Cellulose media 3 micron © > 2 Media area: 0.113 m<sup>2</sup>

Efficiency and lower Efficient and easy to use drainingsystem



Cellulose media 10 micron © > 2 Media area: 0.113 m<sup>2</sup>



Over 1/3 more lab life efficiency at 75 mbar on outer element. Up to 50% more efficiency at 20 and 50 mbar on inner element.

Bobcat higher efficiency filters can reduce up to 30 times dust contamination!





Cellulose media 10 micron © > 2 Media area: 0.113 m<sup>2</sup>

Beta 2 nominal: 4µ Beta 75 absolute: about half from local sources. Media: Synthetic

Synthetic media with min. 50% greater efficiency.

Beta 2 nominal: 10µ Beta 75 absolute: about twice Bobcat specs. Media: Cellulose

# FILTERING OUT THE DIFFERENCE

# **BOBCAT FILTER**

# DODCAI TILILI

Thicker metal housing for superior durability.

## **COMPETITIVE FILTERS\***







Thinner metal housing is more susceptible to dents and failing under pressure.

NTERNAL SPRING

CANISTER ASSEMBLY



25.9

Heavy duty spring holds the filter cartridge firmly in the center of the canister to provide the optimum flow performance.



Internal spring can be weaker, and more vulnerable to breakage. A weaker spring does not hold the cartridge as tightly in place.

FILTER MEDIA



Filter media is uniformly pleated and spaced for maximum filtration surface area. Thicker media ensures the right balance of filter efficiency, capacity, and pressure drop to meet Bobcat Engineering standards.



Inconsistent and fewer media pleats reduce the filtration product life. Competitors may use a thinner media which limits holding capacity. Filters with lower micron ratings will not capture contaminants as effectively and may damage equipment.

INTERNAL BYPASSING



Internal bypass valve is a specially engineered pressed board seal that seals tightly to protect against internal leaking of unfiltered oil.





Bypass valve may not fasten tightly and can leak oil into the system without passing through the filter media. Some brands may lack pressure bypass valves.

SEAL



Wide one-piece seal provides maximum coverage area to protect against leaks.





Seals may pull double duty as a bypass, or be made of more than one-piece creating the opportunity for leaks.

MEDIA Constructio



Filter media is deeply embedded in plasitsol with metal end caps that wrap around to hold media securely. Louvered inner liner allows maximum flow and minimum restriction.





Some competitive brands use glue to adhere media to paper end caps without a ledge, making the filter susceptible to moisture and leakage. Limited inner liner flow area can cause restriction.

INLETS



Greater number of large inlet holes enables better flow through the Bobcat filter. Spin-on Bobcat filters have deep thread engagements for a secure fit.







Smaller, and fewer, inlet holes may restrict flow causing pressure fluctuations. Less thread engagement may cause the filter to be easily stripped off, or allow leaks to occur.




### How do micron ratings relate to filters?

Micron ratings are assigned to filters to indicate the filter's ability to capture certain sizes of particles.

particles.
Because filter media can vary, so can the capability to capture harmful contaminants. It is crucial that systems are correctly matched with specific micron-rated filters to ensure dangerous contaminants are captured.

### Micron particle size comparison




\*Note: The outer canisters of competitive filters have been digitally altered to remove brand information. Internal construction may vary by manufacturer and type of filter. Illustrations not to scale. Bobcat reserves the right to make changes to product specifications and design without notice.

# **SEE THE DIFFERENCE!**

Memorize these six features & benefits to show customers the importance of a quality filter.





### Spin-on design

Provides easy servicing and reduces risk of contamination to the hydraulic system during filter service.

### **Heavy duty metal housing**

Provides superior durability and protects.

### Synthetic filter media

High performance media protects your machine from contaminants and extends service life.

### **Pleated media**

Pleats maximize filter surface area for more contaminant holding capacity and longer filter life.

### **Spiral center tube**

Allows more flow area with higher collapse strength.

### Hot melt spacing and wire backing

Maintains pleat separation and allows optimum filter media use, even during cold start-up and flow fluctuations.

450	S/N 5620	FILTER KIT NUMBER	6900608	
		Engine oil filter	6652366	1
		Fuel filter	6511393	1
		Air filter outer	6632071	1
		Hydraulic filter	6599543	1
453-443	ENGINE D750	FILTER KIT NUMBER	6900609	
		Engine Oil Filter	3974113	1
453		Fuel Filter	3885315	1
		Air Filter Outer	897064	1
		Hydraulic Filter	6599543	1
453	ENGINE D 722	FILTER KIT NUMBER	6900610	
		Engine Oil Filter	6671057	1
453 453		Fuel Filter	6667352	1
		Air Filter Outer	897064	1
		Hydraulic Filter	6599543	1
453	S/N 5150 12897 & UP	FILTER KIT NUMBER	6900962	
453	S/N 5151 12900 & UP	Engine Oil Filter	6671057	1
		Fuel Filter	6667352	1
453		Air Filter Outer	6673752	1
		Air Filter Inner	6673753	1
		Hydraulic Filter	6599543	1
463 - MT52	S/N 5199 & 5200	FILTER KIT NUMBER	6901513	
MT52	S/N S/N 5287 & S/N 5288 ONLY	Engine Oil Filter	6671057	1
		Fuel Filter	6667352	1
463		Air Filter Outer	6673752	1
		Air Filter Inner	6673753	1
		Hydraulic Filter	6677652	1
463	S/N 5221, 5222, 5389, 5390	FILTER KIT NUMBER	6901513A	
S70		Engine Oil Filter	6657635	1
		Fuel Filter	6667352	1
		Air Filter Outer	6672467	1
000		Air Filter Inner	6672468	1
		Hydraulic Filter	6677652	1
533	S/N 4990 ISUZU	FILTER KIT NUMBER	7266402	
		Engine Oil Filter	6555779	1
		Fuel Filter	4121609	1
		Air Filter Outer	6646494	1
		Hydraulic Filter	6515541	1
553	S/N 5130	FILTER KIT NUMBER	6900611	
543	5024 13235 & UP	Engine Oil Filter	3974113	1
		Fuel Filter	3885315	1
553		Air Filter Outer	6646494	1
		Air Filter Inner	6598222	1
		Hydraulic Filter	6630494	1
553F - 553AF	EXCEPT PREFIX 5130	FILTER KIT NUMBER	6900612	
		Engine Oil Filter	6657635	1
553		Fuel Filter	6667352	1
Debut.		Air Filter Outer	6672467	1
		l access of	4	
		Air Filter Inner  Hydraulic Filter	6672468	1

S100		FILTER KIT NUMBER	6987536	
		Engine Oil Filter	6657635	1
		Fuel Filter	6667352	1
		Air Filter Outer	6690907	1
		Air Filter Inner	6690908	1
		Hydraulic Filter	6661248	1
T110		FILTER KIT NUMBER	6987731	
		Engine Oil Filter	6675517	1
-4		Fuel Filter	6667352	1
		Air Filter Outer	6690907	1
		Air Filter Inner	6690908	1
CONTRACTOR OF THE PARTY OF THE		Hydraulic Filter	6661248	1
645 - 743		FILTER KIT NUMBER	6900613	
		Engine Oil Filter	6675517	1
		Fuel Filter	3885315	1
845 Paris		Air Filter Outer	6598492	1
		Air Filter Inner	6598362	1
		Hydraulic Filter	6598903	1
751	PEUGEOT ENGINE	FILTER KIT NUMBER	6900615	
731	reddedt endine	Engine Oil Filter	6661011	1
		Fuel Filter	6667352	1
751		Air Filter Outer	6666333	1
		Air Filter Inner	6666334	1
		Hydraulic Filter	6661248	1
751 - 753 - 763 - 773 (G)		FILTER KIT NUMBER	6900616	
S130 - S150 - T140		Engine Oil Filter	6675517	1
		Liigilie Oil Filtei	00/331/	'
S160 - S175 - S185 - S205 - T180 - T190	EXCEPT S/N´S STARTING WITH A3L & AEY	Fuel Filter	6667352	1
		Air Filter Outer	6598492	1
		Air Filter Inner	6598362	1
		Hydraulic Filter	6661248	1
For machines with hydraulic fan motor: Not in	n kit, order separately!	Hydraulic Fan Filter	6686926	1
S160 - S175 - S185 - S205 - T180 - T190	ALL S/N´S STARTING WITH A3L & AEY (INTERIM TIER4)	FILTER KIT NUMBER	6987629	
A-6-1		Engine Oil Filter	6675517	1
- FR		Fuel Filter	6667352	1
		Air Filter Outer	6698057	1
		Air Filter Inner	6698058	1
		Hydraulic Filter	6661248	1
		Hydraulic Fan Filter	6686926	1
853		FILTER KIT NUMBER	6900617	
		Engine Oil Filter	6659329	1
		Fuel Filter	6667352	1
B53 Steel		Air Filter Outer	6598492	1
		Air Filter Inner	6598362	1
		Hydraulic Filter	6661248	2
863 - 863H - 873 - T200 - A220	0	FILTER KIT NUMBER	6900618	
A300	PREFIX 5211, 5212	Engine Oil Filter	6665603	1
		Fuel Filter	6667352	1
ASSI		Air Filter Outer	6666375	1
		Air Filter Inner	6666376	1
		Hydraulic Filter	6661248	1

S630 S	/N A3NT11548 / A3NU11004 & UP	FILTER KIT NUMBER	6987756	
S650 S	/N A3NV11445 / A3NW11101 & UP	Engine Oil Filter	6678233	1
T630 S	/N A7PU11326 & UP	Fuel Filter	6667352	1
T650 S	/N A3P011191 / A3P111101 & UP	Air Filter Outer	7008043	1
P. A. K		Air Filter Inner	7008044	1
		Hydraulic Filter	7012314	1
		Hydraulic Filter Seal	7015308	1
		Hydraulic Fan Filter	6692337	1
T450 S	/N B1EM11001	FILTER KIT NUMBER	7267107	
S630 S	/N B2L511001	Engine Oil Filter	7030303	1
S650 S	/N B2LA11001	Fuel Filter	7023589	1
T650 S	/N B2KZ11001	Air Filter Outer	7221933	1
		Air Filter Inner	7221934	1
		Hydraulic Filter	7024037	1
		Hydraulic Fan Filter	6692337	1
S510 - S530		FILTER KIT NUMBER	6987863	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
in female		Air Filter Outer	6666333	1
		Air Filter Inner	6666334	1
		Hydraulic Filter	7024037	1
		Hydraulic Fan Filter	6692337	1
S450 - S510 - S530 - S550 - S570	) - S590 - T590	FILTER KIT NUMBER	6987864	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
P Bhart	Air Filter Outer	6666375	1	
		Air Filter Inner	6666376	1
		Hydraulic Filter	7024037	1
		Hydraulic Fan Filter	6692337	1
S220 - S250 - S300 - S330 - A30 STANDARD HYDRAULICS	0 - T250 - T300 - T320 ONLY	FILTER KIT NUMBER	6902266	
		Engine Oil Filter	6678233	1
		Fuel Filter	6667352	1
		Air Filter Outer	6681474	1
		Air Filter Inner	6681475	1
		Hydraulic Filter	6661248	1
For machines with hydraulic fan motor: Not in ki		Hydraulic Fan Filter	6692337	1
S220 - S250 - S300 - S330 - A30 HIGH-FLOW HYDRAULICS	0 - T250 - T300 - T320 ONLY	FILTER KIT NUMBER	6987541	
		Engine Oil Filter	6678233	1
		Fuel Filter	6667352	1
		Air Filter Outer	6681474	1
		Air Filter Inner	6681475	1
		Hydraulic Filter	6668819	1
For machines with hydraulic fan motor: Not in ki		Hydraulic Fan Filter	6692337	1
	/N START WITH A3, A5 OR AA IER3 OR INTERIM TIER4 ENGINE	FILTER KIT NUMBER	6987630	
T250 - T300 - T320 O	ONLY STANDARD HYDRAULICS	Engine Oil Filter	6678233	1
2		Fuel Filter	6667352	1
AST		Air Filter Outer	6698057	1
		Air Filter Inner	6698058	1
		Hydraulic Filter	6661248	1
		Hydraulic Fan Filter	6692337	1

S220 - S250 - S300 - S330 - A300	S/N START WITH A3, A5 OR AA TIER3 OR INTERIM TIER4 ENGINE	FILTER KIT NUMBER	6987631	
T250 - T300 - T320	ONLY HIGH-FLOW HYDRAULICS	Engine Oil Filter	6678233	1
		Fuel Filter	6667352	1
		Air Filter Outer	6698057	1
		Air Filter Inner	6698058	1
		Hydraulic Filter	6668819	1
		Hydraulic Fan Filter	6692337	1
953	S/N 5131	FILTER KIT NUMBER	6900619	
		Engine Oil Filter	6511766	1
		Fuel Filter	3885315	1
953 Botcat		Air Filter Outer	6630939	1
		Air Filter Inner	6630940	1
		Hydraulic Filter	6661248	2
963 (G)	S/N 5165	FILTER KIT NUMBER	6900620	
		Engine Oil Filter	6511766	1
		Fuel Filter	6670996	1
963		Fuel Filter (2nd)	6671649	1
O Ho BOUTAI		Air Filter Outer	6681474	1
		Air Filter Inner	6681475	1
		Hydraulic Filter	6668819	1
S750 - S770 - S850 - T750 - T	770 - T870 - A770	FILTER KIT NUMBER	6987750	
		Engine Oil Filter	6678233	1
		Fuel Filter	6667352	1
® Bolest		Air Filter Outer	7010030	1
		Air Filter Inner	7010031	1
		Hydraulic Filter	7012314	1
		Hydraulic Filter Seal	7015308	1
		Hydraulic Fan Filter	6692337	1
A770	S/N B3BU 11001	FILTER KIT NUMBER	7267108	
S770	S/N B3BV11001	Engine Oil Filter	7030303	1
S850	S/N B3BY11001	Fuel Filter	7023589	1
T870	S/N B3BZ 11001	Air Filter Outer	7010030	1
		Air Filter Inner	7010031	1
		Hydraulic Filter	7248874	1
		Hydraulic Fan Filter	6686926	1
AL275	S/N A01L	FILTER KIT NUMBER	6902906	
		Engine Oil Filter	6675517	1
		Fuel Filter	6683139	1
		Fuel Filter Assembly	6683101	1
		Air Filter Outer	5501660912	1
		Air Filter Inner	5501660914	1
		Hydraulic Filter	5003650368	1
AL275	S/N ADBH	FILTER KIT NUMBER	6987570	
T-		Engine Oil Filter	5411642211	1
		Fuel Filter	5411656301	1
		Air Filter Outer	5501660912	1
		Air Filter Inner	5501660914	1
		Hydraulic Filter	5003650368	1

AL350	A01M	FILTER KIT NUMBER	6902907	
AL440	A01N	Engine Oil Filter	6678233	1
_		Fuel Filter	6689336	1
1		Fuel Filter Assembly	6683101	1
		Air Filter Outer	5501660912	1
		Air Filter Inner	5501660914	1
		Hydraulic Filter	5003659218	1
AL350	S/N ADBJ	FILTER KIT NUMBER	6987571	
AL440	S/N ADBK	Engine Oil Filter	5411642211	1
1		Fuel Filter	5411656301	1
		Air Filter Outer	5501660912	1
	Air Filter Inner	5501660914	1	
		Hydraulic Filter	5003659218	1
MT50 (AND 320D/G - 322D/	G)	FILTER KIT NUMBER	6901188	
		Engine Oil Filter	6671057	1
Bolea		Fuel Filter	6667352	1
		Air Filter Outer	6673752	1
		Air Filter Inner	6673753	1
		Hydraulic Filter	6653336	1
MT52	S/N 5287 & S/N 5288 ONLY	FILTER KIT NUMBER	7266548	
MT55		Engine Oil Filter	6671057	1
Tierll Engine		Fuel Filter	6667352	1
		Air Filter Outer	6687262	1
		Air Filter Inner	6687263	1
		Hydraulic Filter	6677652	1

316		FILTER KIT NUMBER	6902864	
		Engine Oil Filter	6671057	1
Angel Company		Fuel Filter	15231-4356-0	1
		Air Filter Outer	19167-1108-0	1
		Hydraulic Filter	12514-1102	1
E08 - E10 - E14 - E16 - 319 - 32	0D/G - 321 - 322D/G - 323J/K	FILTER KIT NUMBER	6901188	
_		Engine Oil Filter	6671057	1
		Fuel Filter	6667352	1
		Air Filter Outer	6673752	1
		Air Filter Inner	6673753	1
		Hydraulic Filter	6653336	1
220	S/N 12000 & UP	FILTER KIT NUMBER	6900603	
220	S/N 15000 & UP	Engine Oil Filter	3974113	1
320	ENGINE D750	Fuel Filter	6667352	1
		Air Filter Outer	897064	1
		Hydraulic Filter	6653336	1
320 - 322	ENGINE D 722	FILTER KIT NUMBER	6900979	
		Engine Oil Filter	6671057	1
		Fuel Filter	6667352	1
		Air Filter Outer	897064	1
		Hydraulic Filter	6653336	1
325	S/N 5140 11000 - 14899	FILTER KIT NUMBER	6900604	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
		Air Filter Outer	6598492	1
		Air Filter Inner	6598362	1
		7 III T III CET III III CET		
		Hydraulic Filter	6653336	1
325	S/N 5140 14900 & UP			1
325 328	S/N 5140 14900 & UP S/N 5623 11000 & UP	Hydraulic Filter	6653336	1
		Hydraulic Filter FILTER KIT NUMBER	6653336 6900614	
		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter	6653336 <b>6900614</b> 6675517	1
		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter	6653336 <b>6900614</b> 6675517 6667352	1
		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer	6653336 6900614 6675517 6667352 6672467	1 1 1
		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner	6653336 <b>6900614</b> 6675517 6667352 6672467 6672468	1 1 1 1
328		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter	6653336 <b>6900614</b> 6675517 6667352 6672467 6672468 6653336	1 1 1 1
328		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER	6653336 <b>6900614</b> 6675517 6667352 6672467 6672468 6653336 <b>6901190</b>	1 1 1 1 1
328		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517	1 1 1 1 1 1
328		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352	1 1 1 1 1 1 1 1
328 325D/G/K - 328D/G/K - 329K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 66672467	1 1 1 1 1 1 1 1
328		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468	1 1 1 1 1 1 1 1 1 1
328 325D/G/K - 328D/G/K - 329K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468	1 1 1 1 1 1 1 1 1 1
328 325D/G/K - 328D/G/K - 329K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Filter KIT NUMBER	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352	1 1 1 1 1 1 1 1 1 1
328 325D/G/K - 328D/G/K - 329K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Filter Inner  Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Fuel Filter  Air Filter Outer	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 66672468 6661248 6900612 6667635 6667352 6667352	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328 325D/G/K - 328D/G/K - 329K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Outer  Air Filter Inner  Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Air Filter Outer  Air Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Outer	6653336 6900614 6675517 6667352 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6667352 66672467	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Filter Inner  Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6667352	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328 325D/G/K - 328D/G/K - 329K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Air Filter Inner  Hydraulic Filter  Fuel Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fydraulic Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6661248 7256941	1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Outer  Air Filter Inner Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Inner Hydraulic Filter  Fuel Filter  Air Filter Inner Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Number  Fuel Filter  Filter Kit Number  Filter Outer  Air Filter Inner Hydraulic Filter  Filter Kit Number  Engine Oil Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6661248 7256941	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Outer  Air Filter Inner Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner Hydraulic Filter  Filter Outer  Air Filter Inner Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner Hydraulic Filter  Fyel Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter	6653336 6900614 6675517 6667352 6672467 66673536 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6661248 7256941	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Fuel Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Fuel Filter  Fuel Filter  Fuel Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Fuel Filter	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6661248 7256941 6671057 7247169	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Fuel Filter  Fuel Filter  Fuel Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Fuel Filter KIT NUMBER	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6661248 7256941 6671057 7247169 6667352 7176099	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Outer  Air Filter Inner Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner Hydraulic Filter  Filter KIT NUMBER  Engine Oil Filter  Filter Outer  Air Filter Under  Air Filter Inner Hydraulic Filter  Fuel Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Inner Hydraulic Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Fuel Filter Vater Separator  Air Filter  Air Filter Outer	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 667352 6672467 6672468 6661248 6900612 6667352 6667352 6672467 66672468 6661248 7256941 6671057 7247169 6667352 7176099 6673752	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
328  325D/G/K - 328D/G/K - 329K  425K - 428K		Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Outer  Air Filter Inner  Hydraulic Filter  Fuel Filter  Filter KIT NUMBER  Engine Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Fuel Filter  Air Filter Outer  Air Filter Outer  Air Filter Fuel Filter  Fuel Filter  Fuel Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Fuel Filter KIT NUMBER  Engine Oil Filter  Fuel Filter KIT NUMBER	6653336 6900614 6675517 6667352 6672467 6672468 6653336 6901190 6675517 6667352 6672467 6672468 6661248 6900612 6667635 6667352 6672467 6672468 6661248 7256941 6671057 7247169 6667352 7176099	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Engine Offisher   6677352   1	E25		FILTER KIT NUMBER	6987753	
### AN Piller Chair*   6679173   1    AR Filter Inver*   6679773   1    Purpose Piller Filter (Sear Grain)   1000   1000   1    Purpose Piller Filter (Sear Grain)   1000   1000   1    Purpose Piller Filter (Sear Grain)   1000   1000   1    AR Filter RKT NUMBER   69297753   1    AR Filter Enter*   6667372   1    AR Filter Enter*   6667372   1    AR Filter Enter*   6667372   1    AR Filter Enter*   6677373   1    Purpose Piller Filter (Sear Grain)   666744   1    Purpose Piller Filter (Sear Grain)   6677473   1    AR Filter Enter*   6677373   1    Purpose Piller Filter (Sear Grain)   667744   1    AR Filter Enter*   667746   1    AR Filter Chair*   667746   1    AR Filter Chair*   667746   1    Purpose Piller Filter (Sear Grain)   667744   1    AR Filter Chair*   667746   1    Purpose Piller Filter (Sear Grain)   667746   1    AR Filter Chair*   666734   1    AR Filter Chair*   666735   1    AR Filter Chair*   666633   1    AR Filter Chair			Engine Oil Filter	6657635	1
## Apriller Force   Apriller Force   Hydraulic Filter Lane drainin   7000285   1     Hydraulic Filter Lane drainin   7000285   1     Hydraulic Filter Lane drainin   7000285   1     E26	ha		Fuel Filter	6667352	1
Polydaulic Filter (mark filter)			Air Filter Outer	6673752	1
E26	E25		Air Filter Inner	6673753	1
### E26			Hydraulic Filter (case drain)	7009365	1
Eagline Chi Filter			Hydraulic Filter (main filter)	6661248	1
Toel Filter	E26	S/N ACRA	FILTER KIT NUMBER	6987753	
Air Filter Dute  Air Filter Inner  Boday 3733 1 1  Hydraulic Filter (see drain)  E26  S/N AJRY  FILTER KIT NUMBER  6987867  Engine Oil Filter  Air Filter Outer  Air Filter Outer  Air Filter Inner  60672467 1  Air Filter Outer  Air Filter Inner  60672468 1  Hydraulic Filter (see drain)  Filter KIT NUMBER  6987645  Engine Oil Filter  6067247 1  Air Filter Inner  6072467 1  Air Filter Inner  6072467 1  Air Filter Inner  6072468 1  Hydraulic Filter  6072467 1  Air Filter Inner  607246 1  Air Filter Outer  607247 1  Air Filter Outer  607247 1  Air Filter Outer  607247 1  Air Filter Outer  6072	E26	S/N 5623 11000 & UP	Engine Oil Filter	6657635	1
Air Filter Inner Hydraulic Filter (case drain) Hydraulic Filter (c			Fuel Filter	6667352	1
Prystaulic Filter (case drain)	<b>[</b>		Air Filter Outer	6673752	1
Hydraulic Filter (main filter)			Air Filter Inner	6673753	1
Filter KIT NUMBER   6987876	E26		Hydraulic Filter (case drain)	6661248	1
Engine Off Filter			Hydraulic Filter (main filter)	7009365	1
Engine Oil Titler	E26	S/N AJRY	FILTER KIT NUMBER	6987876	
Fuel Filter					1
Air Filter Outer 6672467 1  Air Filter Fourer 6672467 1  Air Filter Inner 6672468 1  Hydraulic Filter (cate drain) 6661248 1  Flydraulic Filter (main filter) 7003865 1  E32 - E35  FILTER KIT NUMBER 6987645  Engine Oil Filter 6667352 1  Air Filter Outer 6667352 1  Air Filter Unter 6667352 1  Air Filter Inner 6667368 1  Hydraulic Filter 76667353 1  Air Filter Outer 6666331 1  Fuel Filter 6666331 1  Air Filter Outer 6666331 1  Air Filter Outer 6666331 1  Fuel Filter 6666331 1  Fuel Filter 6666331 1  Air Filter Outer 6666331 1  Fuel Filter 6666331 1  Fuel Filter 6666331 1  Fuel Filter 6666331 1  Fuel Filter 6666331 1  Air Filter Outer 666649 1  Air Filter Outer 666649 1  Air Filter Outer 666649 1  Hydraulic Filter 666633 1  Fuel Filter 666633 1  Air Filter Outer 666649 1  Air Filter Outer 666633 1			-	6667352	
Air Filter Inner   6672468   1     Hydraulic Filter (rase drain)   6651248   1     Hydraulic Filter (rase final filter)   7003355   1     Filter KITN UMBER   6987645   1     Full Filter   6672467   1     Air Filter Outer   6672467   1     Air Filter finner   6672468   1     Hydraulic Filter   7009365   1     Hydraulic Filter   7009365   1     Hydraulic Filter   6668331   1     Hydraulic Filter   6668331   1     Full Filter   6667352   1     Air Filter Outer   6667352   1     Air Filter Outer   6666334   1     Hydraulic Filter   6668330   1     Full Filter   6668330   1     Air Filter Inner   6666334   1     Air Filter Inner   6666333   1     Air Filter Inner   6666334   1					1
Hydraulic Filter (rase drain)   6661248   1     Hydraulic Filter (main filter)   7009365   1     E32 - E35   FILTER KIT NUMBER   6987645     Engine Oil Filter   6667352   1     Air Filter Oiler   6667352   1     Air Filter Oiler   6667362   1     Hydrostatic Filter   6667362   1     Hydrostatic Filter   666819   1     Hydrostatic Filter   666819   1     Hydrostatic Filter   666833   1     Hydrostatic Filter   6667352   1     Air Filter Oiler   6667352   1     Air Filter Oiler   6667352   1     Air Filter Oiler   6667333   1     Air Filter Oiler   666833   1     Hydraulic Filter   666833   1     Hydraulic Filter   666833   1     Hydraulic Filter   6686630   1     Filter Filter   6686630   1     Fuel Filter   668633   1     Air Filter Oiler   668633   1					
Hydraulic Filter (main filter)   7009365   1		Hydraulic Filter (case drain)	6661248	1	
### FILTER KIT NUMBER    6987645			7009365	1	
Engine Oil Filter   6675317   1 Fuel Filter   6667324   1 Air Filter Outer   6672467   1 Air Filter Outer   6672467   1 Air Filter Inner   6672468   1 Hydraulic Filter   7009365   1 Hydrostatic Filter   6668819   1  331 - 331E - 334   S/N 5129 13000 & UP   FILTER KIT NUMBER   6900605  Engine Oil Filter   6667331   1 Air Filter Outer   6666333   1 Air Filter Inner   6666333   1 Air Filter Filter   6667336   1 Hydraulic Filter   6686336   1 Fuel Filter   6686336   1 Fuel Filter   6686316   1 Air Filter Outer   6646494   1 Hydraulic Filter   6667352   1 Air Filter Outer   6666333   1	E32 - E35		FILTER KIT NUMBER	6987645	
Fuel Filter					1
Air Filter Inner 6672468 1 Hydraulic Filter 7009365 1 Hydrostatic Filter 7009365 1 Hydrostatic Filter 6668819 1  331 - 331E - 334			Fuel Filter	6667352	1
Hydraulic Filter   7009365   1		Air Filter Outer	6672467	1	
Hydrostatic Filter			Air Filter Inner	6672468	1
SIN 5129 13000 & UP			Hydraulic Filter	7009365	1
Engine Oil Filter			Hydrostatic Filter	6668819	1
Fuel Filter 6667352 1 Air Filter Outer 6666333 1 Air Filter Inner 6666334 1 Hydraulic Filter 6653336 1   335	331 - 331E - 334	S/N 5129 13000 & UP	FILTER KIT NUMBER	6900605	
Air Filter Outer 6666333 1  Air Filter Inner 6666334 1  Hydraulic Filter 6653336 1  335			Engine Oil Filter	6675517	1
Air Filter Inner 6666334 1 Hydraulic Filter 6653336 1  335 S/N 5116 FILTER KIT NUMBER 6900606  Engine Oil Filter 6686216 1 Fuel Filter 6686630 1 Fuel Filter 6686630 1 Air Filter Outer 6646494 1 Hydraulic Filter 6692744 1  331 - 334D/G/K - 335 (S/N A16U) FILTER KIT NUMBER 6901191  Engine Oil Filter 6667352 1 Air Filter Outer 666633 1 Air Filter Outer 666633 1 Air Filter Fuel Filter 6667352 1 Air Filter Number 6901191  430 FILTER KIT NUMBER 6987542  Engine Oil Filter 6667352 1 Air Filter Miller Miller 6667352 1 Air Filter Outer 666633 1 Air Filter Outer 666633 1 Air Filter Miller Miller 667352 1 Air Filter Miller Miller 6667352 1 Air Filter Miller Miller 666733 1 Air Filter Miller Miller 666633 1 Air Filter Miller M	A )		Fuel Filter	6667352	1
Hydraulic Filter			Air Filter Outer	6666333	1
Solution	CHID.		Air Filter Inner	6666334	1
Engine Oil Filter 6686216 1 Fuel Filter 6686630 1 Fuel Filter (2nd) 7000981 1 Air Filter Outer 6646494 1 Hydraulic Filter 6692744 1  331 - 334D/G/K - 335 (S/N A16U)  FILTER KIT NUMBER 6901191  Engine Oil Filter 6675517 1 Fuel Filter 0uter 6666333 1 Air Filter Outer 6666334 1 Hydraulic Filter 6667552 1  Air Filter Inner 666634 1  Filter KIT NUMBER 6987542  Engine Oil Filter 667352 1  Air Filter Miter 6667352 1  Air Filter 667352 1  Air Filter 6667352 1  Air Filter 6667352 1  Air Filter 6667352 1  Air Filter 667352 1  Air Filter 667352 1			Hydraulic Filter	6653336	1
Fuel Filter 6686630 1 Fuel Filter (2nd) 7000981 1 Air Filter Outer 6646494 1 Hydraulic Filter 6692744 1  S31 - 334D/G/K - 335 (S/N A16U) FILTER KIT NUMBER 6901191 Engine Oil Filter 6667352 1 Air Filter Outer 6666333 1 Air Filter Inner 666634 1 Hydraulic Filter 6675517 1 Engine Oil Filter 6667352 1 Air Filter Inner 6666334 1 Air Filter Inner 6666334 1 FILTER KIT NUMBER 6987542 Engine Oil Filter 6667352 1 Air Filter Outer 6666333 1 Air Filter Outer 6666333 1 Air Filter Outer 6666334 1	335	S/N 5116	FILTER KIT NUMBER	6900606	
Fuel Filter (2nd) 7000981 1 Air Filter Outer 6646494 1 Hydraulic Filter 6692744 1  331 - 334D/G/K - 335 (S/N A16U)  FILTER KIT NUMBER 6901191  Engine Oil Filter 6667352 1 Air Filter Outer 6666333 1 Air Filter Inner 6666334 1 Hydraulic Filter 6667352  FILTER KIT NUMBER 6987542  Engine Oil Filter 6667352 1  Air Filter Under 6666333 1 Air Filter Outer 6666333 1 Air Filter Outer 6666334 1 Filter KIT NUMBER 6987542  Engine Oil Filter 6667352 1 Air Filter Outer 6666333 1 Air Filter Outer 6666333 1 Air Filter Outer 6666333 1					1
Air Filter Outer 6646494 1  Hydraulic Filter 6692744 1  331 - 334D/G/K - 335 (S/N A16U)  FILTER KIT NUMBER 6901191  Engine Oil Filter 6675517 1  Fuel Filter 6667352 1  Air Filter Outer 6666334 1  Hydraulic Filter 6667248 1  430  FILTER KIT NUMBER 6987542  Engine Oil Filter 6667352 1  Air Filter Unmater 6666333 1  Air Filter Unmater 6666333 1  Air Filter Outer 6666333 1  Air Filter Outer 6666334 1			Fuel Filter	6686630	1
Hydraulic Filter   6692744   1			Fuel Filter (2nd)	7000981	1
Section   Sect			Air Filter Outer	6646494	1
Engine Oil Filter 6675517 1 Fuel Filter 6667352 1 Air Filter Outer 6666333 1 Air Filter Inner 666634 1 Hydraulic Filter 6661248 1  FILTER KIT NUMBER 6987542 Engine Oil Filter 6667352 1 Air Filter Outer 666633 1 Air Filter Outer 666633 1 Air Filter Outer 666633 1			Hydraulic Filter	6692744	1
Fuel Filter 6667352 1  Air Filter Outer 6666333 1  Air Filter Inner 6666334 1  Hydraulic Filter 6661248 1  430 FILTER KIT NUMBER 6987542  Engine Oil Filter 6667352 1  Air Filter Outer 6666333 1  Air Filter Outer 6666333 1  Air Filter Inner 6666334 1	331 - 334D/G/K - 335 (S/N A1	6U)	FILTER KIT NUMBER	6901191	
Air Filter Outer 6666333 1  Air Filter Inner 6666334 1  Hydraulic Filter 6661248 1  430  FILTER KIT NUMBER 6987542  Engine Oil Filter 66675517 1  Fuel Filter 6667352 1  Air Filter Outer 6666333 1  Air Filter Inner 6666334 1			Engine Oil Filter	6675517	1
Air Filter Inner 6666334 1  Hydraulic Filter 6661248 1  430  FILTER KIT NUMBER 6987542  Engine Oil Filter 66675517 1  Fuel Filter 6667352 1  Air Filter Outer 6666333 1  Air Filter Inner 6666334 1	Mail		Fuel Filter	6667352	1
Hydraulic Filter 6661248 1  430 FILTER KIT NUMBER 6987542  Engine Oil Filter 6675517 1  Fuel Filter 6667352 1  Air Filter Outer 6666333 1  Air Filter Inner 6666334 1			Air Filter Outer	6666333	1
FILTER KIT NUMBER   6987542			Air Filter Inner	6666334	1
Engine Oil Filter         6675517         1           Fuel Filter         6667352         1           Air Filter Outer         6666333         1           Air Filter Inner         6666334         1			Hydraulic Filter	6661248	1
Fuel Filter       6667352       1         Air Filter Outer       6666333       1         Air Filter Inner       6666334       1	430		FILTER KIT NUMBER	6987542	
Air Filter Outer         6666333         1           Air Filter Inner         6666334         1			Engine Oil Filter	6675517	1
Air Filter Inner         6666334         1	Man To		Fuel Filter	6667352	1
			Air Filter Outer	6666333	1
Hydraulic Filter 6668819 1			Air Filter Inner	6666334	1
			Hydraulic Filter	6668819	1

-11

435D/G/AG/HAG		FILTER KIT NUMBER	6902865	
		Engine Oil Filter	6675517	1
In Indian		Fuel Filter	6667352	1
		Air Filter Outer	6666375	1
		Air Filter Inner	6666376	1
		Hydraulic Filter	6668819	1
337 - 341	S/N 5154 & 2306	FILTER KIT NUMBER	6900607	
337 - 341	3/N 3134 & 2300		6675517	1
		Engine Oil Filter		
		Fuel Filter	6667352	1
		Air Filter Outer Air Filter Inner	6666333	1
			6666334	1
		Hydraulic Filter	6670207	1
337D/G/K - 341D/G/K		FILTER KIT NUMBER	6901189	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
		Air Filter Outer	6666375	1
		Air Filter Inner	6666376	1
		Hydraulic Filter	6670207	1
E45		FILTER KIT NUMBER	6987751	
		Engine Oil Filter	6675517	1
A CONTRACTOR		Fuel Filter	6667352	1
	Air Filter Outer	6666375	1	
	Air Filter Inner	6666376	1	
	Hydraulic Filter (case drain)	6516722	1	
		Hydraulic Filter (main filter)	6668819	1
E50 - E55		FILTER KIT NUMBER	6987752	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
		Air Filter Outer	6666375	1
		Air Filter Inner	6666376	1
		Hydraulic Filter (case drain)	6516722	1
		Hydraulic Filter (main filter)	6670207	1
F60 F63				'
E60 - E62		FILTER KIT NUMBER	6987574	
		Engine Oil Filter	7025590	1
		Fuel Filter	7010351	1
		Fuel Prefilter	7013148	1
		Air Filter Outer	6666333	1
		Air Filter Inner	6666334	1
		Hydraulic return	7004883	1
		Hydraulic pilot	7011915	1
		Hydraulic breather	7006806	1
442 60114	C/N 5222 44444 0 115	Air condition	7006085	1
442 COM1	S/N 5223 11001 & UP	FILTER KIT NUMBER	6902267	
		Engine Oil Filter	5411316400	1
		Fuel Filter	5445100004	1
		Fuel Filter (2nd)	5411656567	1
		Air Filter Outer	5501660912	1
		Air Filter Inner	5501660914	1
		Hydraulic Filter	5380658088	1
442 COM2	S/N 5286 11001 & UP	FILTER KIT NUMBER	6902911	
442 COM3	ADBR & ADBS	Engine Oil Filter	5411642211	1
7 (A) (C) (A) (A) (A) (A) (A) (A) (A) (A) (A) (A		Fuel Filter Inline	6687016	1
		Fuel Filter (2nd)	5411656301	1
		Air Filter Outer	5501660912	1
2		Air Filter Inner	5501660914	1
		Hydraulic Filter	5368632568	1
		Try dradine tritter	3300032300	1 '

E80	FILTER KIT NUMBER	6987575	
	Engine Oil Filter	7010347	1
	Fuel Filter	7010351	1
	Fuel Prefilter	7013148	1
	Air Filter Outer	6666333	1
The state of the s	Air Filter Inner	6666334	1
	Hydraulic return	7004884	1
	Hydraulic pilot	7011915	1
	Hydraulic breather	7006806	1
	Air condition	7006085	1
E85	FILTER KIT NUMBER	7031399	
1	Engine Oil Filter	7025590	1
	Fuel Filter	7029016	1
	Fuel Prefilter	7029012	1
	Air Filter Outer	6666333	1
	Air Filter Inner	6666334	1
	Hydraulic return	7004884	1
	Hydraulic pilot	7011915	1
	Hydraulic breather	7006806	1
	Air condition	7006085	1
444 S/N 5322 11001& UP	FILTER KIT NUMBER	6902909	
<del>-</del> 3	Engine Oil Filter	5501316450	1
	Fuel Filter	5411657780	1
	Fuel Filter (2nd)	5411656493	1
	Air Filter Outer	5501660922	1
	Air Filter Inner	5501660924	1
	Hydraulic Filter	5380658088	1
444 COM3 ADBT S/N 11001& UP	FILTER KIT NUMBER	6007630	
	TIETER RIT ROMDER	6987628	
- N	Engine Oil Filter	5501316450	1
			1
	Engine Oil Filter	5501316450	
	Engine Oil Filter Fuel Filter Tank	5501316450 5411657780	1
	Engine Oil Filter Fuel FilterTank Fuel Filter	5501316450 5411657780 5411657146	1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer	5501316450 5411657780 5411657146 5501660922	1 1 1
E55W	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner	5501316450 5411657780 5411657146 5501660922 5501660924	1 1 1 1
	Engine Oil Filter  Fuel Filter Tank  Fuel Filter  Air Filter Outer  Air Filter Inner  Hydraulic Filter	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088	1 1 1 1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter FILTER KIT NUMBER	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b>	1 1 1 1 1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter FILTER KIT NUMBER Engine Oil Filter	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b> 7010347	1 1 1 1 1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter FILTER KIT NUMBER Engine Oil Filter Fuel Filter	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b> 7010347 7010351	1 1 1 1 1 1 1 1 1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter Engine Oil Filter Fuel Filter Fuel Prefilter	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b> 7010347 7010351 7013148	1 1 1 1 1 1 1 1 1 1
	Engine Oil Filter  Fuel Filter Tank  Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter  Fuel Prefilter  Air Filter Outer	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b> 7010347 7010351 7013148 6666333	1 1 1 1 1 1 1 1 1 1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter FILTER KIT NUMBER Engine Oil Filter Fuel Filter Fuel Prefilter Air Filter Outer Air Filter Inner	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b> 7010347 7010351 7013148 6666333 6666334	1 1 1 1 1 1 1 1 1 1 1
	Engine Oil Filter Fuel Filter Tank Fuel Filter Air Filter Outer Air Filter Inner Hydraulic Filter FILTER KIT NUMBER Engine Oil Filter Fuel Filter Fuel Prefilter Air Filter Outer Air Filter Inner Hydraulic return	5501316450 5411657780 5411657146 5501660922 5501660924 5380658088 <b>6987573</b> 7010347 7010351 7013148 6666333 6666334 7004883	1 1 1 1 1 1 1 1 1 1 1 1

# **TELESCOPIC HANDLERS**

ATMOSPHERIC ENGINES	FILTER KIT NUMBER	6901923A	
T2556, T2566, T3071, T3093, T40140, T40170 AND T40150*	Hydrostatic Transm. Filter	75990.2	1
Tier I Engines	Hydraulic Filter	82139.7	1
	Air Filter Outer	75692.4	1
	Air Filter Inner	75693.2	1
	Fuel Filter	64978	1
	Engine Oil Filter	6511766	1
*For 40150, use kit 6901923T and 1x 81120.8	*Filter element	*81120.8	1
TURBO ENGINES	FILTER KIT NUMBER	6901923T	
T2556, T2566, T3071, T3093, T40140, T40170 AND T40150 *	Hydrostatic Transm. Filter	75990.2	1
Tier I Engines	Hydraulic Filter	82139.7	1
	Air Filter Outer	75686.6	1
	Air Filter Inner	75687.4	1
	Fuel Filter	64978	1
*For 40150, use kit 6901923T and 1x 81120.8	*Filter element	6511766 *81120.8	1
T2556 - S/N 3630 11001 TO 11015	FILTER KIT NUMBER	7266550	'
T2566 - S/N 3631 11001 TO 11006	Engine Oil Filter	6911905	1
T40140 - S/N 3632 11001 TO 11038	Fuel Filter	6911907	1
T40170 - S/N 3633 11001 TO 11061	Air Filter Outer	6910725	1
New Generation Tier II Perkins Engines	Air Filter Inner	6910726	1
	Hydraulic Filter	6913059	1
T2556 - 3630 11016 AND UP	FILTER KIT NUMBER	6902912	
T2566 - 3631 11007 AND UP	Engine Oil Filter	6511766	1
T3571 (L) - S/N 3628 (3629)	Fuel Filter	6911907	1
T35100 (L/S/SL) - S/N 3666(3663/3665/3662)	Air Filter Outer	6910725	1
T35120 L(SL) - S/N 3627-3637 (3626-3638) 11001 AND UP	Air Filter Inner	6910726	1
T40140 - 3632 11039 AND UP - 3639 13001 AND UP	Hydraulic Filter	6913059	1
T40170 - 3633 11062 AND UP - 3654 11001 AND UP			
New Generation Tier II Perkins Engines			
Not in kit, order separately	Hydr. Breather 16,6 mm	6917778	1
	Cap Hydr. Breather	6917779	1
On some T40140-T40170 Tier II, there is also a version with hydr. breather ca 12 mm	Hydr. Breather ca. 12 mm (not in kit)	37148.4	1
	Cap Hydr. Breather (not in kit)	6913567	1
T2556 - A8FR 11001 AND UP	FILTER KIT NUMBER	6987674	
T2566 - A8G3 11001 AND UP	Engine Oil Filter	960698	1
T3571 (L) - A8HF(A8H6)	Fuel Filter	6911907	1
T35100 (L/SL) - A8HD(A8GW/A8GT)	Fuel Prefilter Element	7001034	1
T35120 L(SL) - A8GV(A8GJ-A8GS) 11001 AND UP	Air Filter Outer	6910725	1
T40140 - A8GA 11001 AND UP	Air Filter Inner	6910726	1
T40170 - A8GB 11001 AND UP	Hydraulic Filter	6913059	1
New Generation Tier III Perkins Engines		·	
T2250 - S/N A859	FILTER KIT NUMBER	6987540	
Tier II Kubota Engines	Engine Oil Filter	6678233	1
\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	Fuel Filter	6667352	1
	Air Filter Outer	6910725	1
	Air Filter Inner	6910726	1
	Hydraulic Charge Pressure Filter	6661248	1
	Hydraulic Filter	6919493	1

# **TELESCOPIC HANDLERS**

T2250 - S/N AC19		FILTER KIT NUMBER	6987632	
Tier III Kubota Engines		Engine Oil Filter	6678233	1
		Fuel Filter	6667352	1
		Air Filter Outer	75686.6	1
		Air Filter Inner	75687.4	1
		Hydraulic Charge Pressure Filter	6661248	1
		Hydraulic Filter	6919493	1
Not in kit, order separately		Hydr. Breather 16,6 mm	6917778	1
		Cap Hydr. Breather	6917779	1
T40140 - T40180 PF4 (STAGE	EIIIA)	FILTER KIT NUMBER	7031408	
T35105	B3GN11001 & UP	Engine Oil Filter	960698	1
T35105L	B3GP11001 & UP	Fuel Filter Element	6911907	1
T36120SL	B3GS11001 & UP	Fuel Prefilter Element	7001034	1
		Air Filter Outer	6910725	1
		Air Filter Inner	6910726	1
		Hydr. Oil Filter	7225338	2
Not in kit, order separately		Air condition	7228497	1
T40140 - T40180 (STAGE IIIB		FILTER KIT NUMBER	6987758	
T35105	B3GU110001 & UP	Engine Oil Filter	960698	1
T35105L	B3GV110001 & UP	Fuel Filter Element	6911907	1
T36120SL	B3GW11001 & UP	Fuel Prefilter Element	7001034	1
		Air Filter Outer	6910725	1
		Air Filter Inner	6910726	1
		Hydr. Oil Filter	7225338	2
Not in kit, order separately		Air condition	7228497	1
TL 360 & 470		FILTER KIT NUMBER	6987747	
•		Engine Oil Filter	960698	1
		Fuel Filter Element	6911907	1
₹ Bhai		-		
		Fuel Filter Element	6911907	1
THE STATE OF THE S		Fuel Filter Element Fuel Prefilter Element	6911907 7001034	1
		Fuel Filter Element Fuel Prefilter Element Air Filter Outer	6911907 7001034 6910725	1 1 1
		Fuel Filter Element Fuel Prefilter Element Air Filter Outer Air Filter Inner	6911907 7001034 6910725 6910726	1 1 1
TL 470 HF	130HP	Fuel Filter Element Fuel Prefilter Element Air Filter Outer Air Filter Inner Hydr. Oil Filter	6911907 7001034 6910725 6910726 7012477	1 1 1 1 1
TL 470 HF	130HP	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter	6911907 7001034 6910725 6910726 7012477 7012478	1 1 1 1 1
TL 470 HF	130НР	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER	6911907 7001034 6910725 6910726 7012477 7012478 6987764	1 1 1 1 1 1
TL 470 HF	130HP	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 <b>6987764</b> 960698	1 1 1 1 1 1
TL 470 HF	130HP	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122	1 1 1 1 1 1 1 1 1
TL 470 HF	130HP	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Fuel Prefilter Element	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160	1 1 1 1 1 1 1 1 1
TL 470 HF	130HP	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725	1 1 1 1 1 1 1 1 1 1
TL 470 HF	130HP	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726	1 1 1 1 1 1 1 1 1 1 1 1
TL 470 HF  TL 470 / 470HF	130HP  120HP PF2 STAGE IIIB DEUTZ	Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
The state of the s		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478	1 1 1 1 1 1 1 1 1 2
The state of the s		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873	1 1 1 1 1 1 1 1 1 1 1 1 1 2
The state of the s		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Filter  FILTER KIT NUMBER  Engine Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
The state of the s		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Hydr. Oil Filter  Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Outer	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725	1 1 1 1 1 1 1 1 1 1 1 2 1
The state of the s		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Outer  Air Filter KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Outer	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
The state of the s		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Unter  Air Filter Inner  Hydr. Oil Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Inner  Fuel Filter Element  Fuel Filter Element  Fuel Filter Element  Hydr. Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910725 6910725 7028353	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
TL 470 / 470HF		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Inner  Hydr. Oil Filter  Fuel Filter Element  Filter Filter Filter  Filter KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Inner  Fuel Filter Element  Fuel Filter Element  Hydr. Oil Filter  Hydr. Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726 7028353 7028352 7012477 7012478	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
T SAUT ON THE SAUT OF THE SAUT		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Inner  Hydr. Oil Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Element  Hydr. Oil Filter  Air Filter Inner  Fuel Filter Element  Hydr. Oil Filter Element  Hydr. Oil Filter Element  Hydr. Oil Filter  Hydr. Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726 7028353 7028352 7012477 7012478 6987757	1 1 1 1 1 1 1 1 1 1 1 1 1 2 1 1 1 1 1 1
TL 470 / 470HF		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Hydr. Oil Filter  Filter KIT NUMBER  Engine Oil Filter  Air Filter Inner  Fuel Filter Element  Fuel Filter Element  Fuel Filter Inner  Fuel Filter Inner  Fuel Filter Element  Fuel Prefilter Element  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726 7028353 7028352 7012477 7012478 6987757 7019876	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
TL 470 / 470HF		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Inner  Hydr. Oil Filter  FILTER KIT NUMBER  Engine Oil Filter  Air Filter Outer  Air Filter Element  Hydr. Oil Filter  Air Filter Inner  Fuel Filter Element  Hydr. Oil Filter Element  Hydr. Oil Filter Element  Hydr. Oil Filter  Hydr. Oil Filter	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726 7028353 7028352 7012477 7012478 6987757 7019876 7019324	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
TL 470 / 470HF		Fuel Filter Element Fuel Prefilter Element Air Filter Outer Air Filter Inner Hydr. Oil Filter Hydr. Oil Hydrostatic charge Filter FILTER KIT NUMBER Engine Oil Filter Fuel Filter Element Air Filter Outer Air Filter Inner Hydr. Oil Hydrostatic charge Filter FILTER KIT NUMBER Engine Oil Filter Hydr. Oil Filter Hydr. Oil Filter FILTER KIT NUMBER Engine Oil Filter Air Filter Outer Air Filter Inner Fuel Filter Element Fuel Filter Element Fuel Filter Element Fuel Filter Element Hydr. Oil Hydrostatic charge Filter FILTER KIT NUMBER Engine Oil Filter Fuel Filter Element Filter Filter Filter Filter Filter Filter Filter Filter Filter Element Filter Filter Element	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726 7028353 7028352 7012477 7012478 6987757 7019876 7019324 7019874	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
TL 470 / 470HF		Fuel Filter Element  Fuel Prefilter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Filter  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Fuel Filter Element  Air Filter Outer  Air Filter Inner  Hydr. Oil Hydrostatic charge Filter  FILTER KIT NUMBER  Engine Oil Filter  Hydr. Oil Filter  Filter Inner  Fyel Filter Element  Air Filter Outer  Air Filter Outer  Air Filter Outer  Air Filter Filter Element  Fuel Filter Element  Fuel Filter Element  Fuel Filter Element  Hydr. Oil Filter  Hydr. Oil Filter  Hydr. Oil Filter  Filter Element  Filter Element  Filter Filter Element  Filter Filter Element  Filter Filter Element	6911907 7001034 6910725 6910726 7012477 7012478 6987764 960698 7017122 7017160 6910725 6910726 7012477 7012478 6987873 7028298 6910725 6910726 7028353 7028352 7012477 7012478 6987757 7019876 7019324	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

# **TELESCOPIC HANDLERS**

TR40250-TR45190-TR50210	FILTER KIT NUMBER	6987758	
<b>≯</b> T1	Engine Oil Filter	960698	1
	Fuel Filter	7017122	1
	Fuel Prefilter Element	7017308	1
	Air Filter Outer	7014693	1
	Air Filter Inner	7014692	1
	Hydr. Oil Filter	7014687	1

# **UTILITY VEHICLES**

TOOLCAT 5600	4247 & UP, 4248 & UP, 5005 & UP, A002 & UP, A003 & UP	FILTER KIT NUMBER	7266551	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
		Air Filter Outer	6666333	1
		Air Filter Inner	6666334	1
		Hydraulic Filter	6516722	1
		Hydrostatic Filter	6668819	1
TOOLCAT 5600	A94Y & UP, AHG8 & UP	FILTER KIT NUMBER	7266552	
		Engine Oil Filter	6675517	1
		Fuel Filter	6667352	1
		Air Filter Outer	7003490	1
		Air Filter Inner	7003489	1
		Hydraulic Filter	6516722	1
		Hydrostatic Filter	6668819	1
2200	PREFIX:2353, A55E, A59Z,	FILTER KIT NUMBER	7266553	
	A5KR, A5A1, A59W	Engine Oil Filter	6671057	1
		Fuel Filter	6667352	1
		Air Filter	6672467	1
3400	S/N STARTING WITH AJNU	FILTER KIT NUMBER	6987871	
3400 XL	S/N STARTING WITH AJNW	Engine Oil Filter	7018465	1
		Fuel Filter	6988961	1
		Air intake filter	7016038	1
		Air intake ducting filter	7016382	1
3400	S/N STARTING WITH AJNT	FILTER KIT NUMBER	6987872	
3400 XL	S/N STARTING WITH AJNV	Engine Oil Filter	7017416	1
		Fuel Filter	7016379	1
		Air intake filter	7016038	1
		Air intake ducting filter	7016382	1

# OTHER EQUIPMENT

BCR150	FILTER KIT NUMBER	N/A	
*\_	Fuel Filter	54475744	1
	Air Clean. (BC90/110)	54475439	1
BC70 / 90 / 110	FILTER KIT NUMBER	N/A	
4. 0	Fuel Filter	54475744	1
(Par	Air Cleaner (BC70)	13221312	1
	Air Clean. (BC90/110)	54475439	1
BAP 7/20	FILTER KIT NUMBER	N/A	
	Engine Filter	22355481	1
	Fuel Filter	22283360	1
	Air Filter	22295794	1
	Separator Element	22305577	1
	Water/Fuel Sep. Filt.	22284640	1
	Compressor Oil Filt.	85052744	1
BAP 7/26	FILTER KIT NUMBER	N/A	
	Engine Filter	22226351	1
	Fuel Filter	22226369	1
The state of the s	Air Filter	54516075	1
	Separator Element	54517776	1
	Water/Fuel Sep. Filt.	54525530	1
	Compressor Oil Filt.	85052744	1
BAP 7/31 & 7/41	FILTER KIT NUMBER	N/A	
	Engine Filter	22226351	1
	Fuel Filter	22226369	1
The state of the s	Air Filter	89232474	1
	Separator Element	54596705	1
	Water/Fuel Sep. Filt.	54525530	1
	Compressor Oil Filt.	36897353	1
BAP 7/51	FILTER KIT NUMBER	N/A	
	Engine Filter	22226351	1
	Fuel Filter	22226369	1
	Air Filter	88110556	1
	Separator Element	54625942	1
	Water/Fuel Sep. Filt.	54525530	1
	Compressor Oil Filt.	36897353	1
BR55	FILTER KIT NUMBER	N/A	
- F	Fuel Filter	59853358	1
	Air Filter Outer	22328710	1
	Air Filter Inner	22328702	1
BR72	FILTER KIT NUMBER	N/A	
•	Fuel Filter	59853358	1
	Air Filter Outer	59244368	1
	Air Filter Inner	59244350	1
BT650 / 750	FILTER KIT NUMBER	N/A	
V.	Fuel Filter	59365775	1
	Air Cleaner	59854315	1
	Oil Filter	59854299	1
	Oil Filter	59838581	1

# TIPS FOR HANDLING AND STORING BOBCAT FILTERS

Whether you are storing filters in your shop or warehouse, it's always important to practice good storage and handling techniques. Here are a few tips to keep your filters in good condition:

- Make sure the filter is clean, unused and free of damage before selling or installing.
- Never store a filter without it being in a box or completely sealed.
- To prevent damage to filters, don't throw in the back of a truck, or in any other area where damage could occur.
- Be sure to keep filters in original packaging if storing on metal shelves. Over time, this will help to prevent rusting.
- Make sure labels with product information and dates are visible to all personnel pulling from shelves.





